



Nosecone top view template

Top plate assembly drawing

Bulkhead F-1  
(make 1)

Fwd Fuselage Bottom (make 1)

Vertical stabilizers  
(make 2)

Bulkhead F-3  
(make 1)

Bulkhead F-2  
(make 1)

Aft Fuselage Slides with Vertical Tails  
(make 2)

Aft Fuselage Bottom  
(make 1)

A2  
(make 2)

Canopy  
(make 11 with 6mm Depron)

Canard wings  
(make 2)

Elevators  
(make 2)

A3  
(make 1)

A1  
(make 2)

Top fwd fuselage  
(trim to fit)

Motor mount  
(make 2 and laminate together)

A4  
(make 1)

A6  
(make 1)

A5  
(make 1)

Nosecone  
(make 11 with 6mm Depron)

Depron  
2 x 6mm

Fwd Fuselage (make 2)

F-1

F-2

F-3

Vertical tail supports  
Fibre-glass sheed PCB 0.8mm  
(make 4)

Elevator supports  
Fibre-glass sheed PCB 0.8mm  
(make 2)

Brake Parachute Housing (make 2)

(make 1)

SU-47 Berkut PART 6mm DEPRON			
size	code	part no	part
A0		SU-47---001	A1
scale	1:1	08-12-2004	RRR

Scale cm 0 5 10

Scale cm 0 5 10

16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1

16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1