

Mixing Differential Thrust by Andy Kunz

There's not a "**differential thrust**" function built-in.

You make it yourself.

One mix of throttle (right engine) to the aux channel for the left engine.

Now 2 more mixes: Mix rudder to right engine and rudder to left engine.

Andy